

SWAGTRON®

T881

HOVERBOARD



USER MANUAL

In order to continue serving our customers and providing the best products, our product information including our user manuals may receive updates from time to time. Please check our website for the latest user manuals and product materials. Ver. 2.0 05/31/18



Thank you for your purchase of the SWAGTRON® T881 Hoverboard by SWAGTRON®!

You're about to take the next step in the evolution of transportation. The T881 takes the fun of a skateboard, the ease of an electric scooter, and tops it off with an extra bit of swag.

To ensure your safety and the safety of others, please read and be sure to follow all instructions and safety recommendations in this user manual prior to and when riding your hoverboard.

If you have any questions regarding the T881, contact us at 1-844-299-0625 for further assistance.

Happy Riding!

-The SWAGTRON® Team

SWAGTRON® T881 User Manual

Table of Contents

I – GENERAL INFORMATION	---	6
1.1 ABOUT THE SWAGTRON® T881	---	6
1.2 WHAT'S IN THE BOX?	---	7
1.3 SAFETY NOTICE	---	7
1.4 IMPORTANT INFORMATION	---	8
1.5 DISPOSAL AT END-OF-LIFE	---	10
II – PRODUCT FEATURES	---	11
2.1 SWAGTRON® T881 DIAGRAM	---	11
2.2 SWAGTRON® SENTRYSHIELD® - PATENTED MULTILAYERED PROTECTION	---	12
2.3 BUILT-IN STARTUP BALANCING	---	12
III – HOW TO RIDE	---	14
3.1 OPERATING STEPS	---	14
3.2 DIAGRAM OF OPERATION	---	15
3.3 CALIBRATION	---	17
IV – SAFE RIDING TECHNIQUES	---	19

V - BATTERY INFORMATION	---	21
5.1 CHARGING THE T881	---	21
5.2 BATTERY INDICATOR	---	22
5.3 RANGE PER CHARGE	---	23
5.4 SAFETY WARNINGS	---	24
VI - MAINTENANCE	---	26
6.1 CLEANING	---	26
6.2 STORAGE	---	27
6.3 TRANSPORTATION	---	27
VII - SWAGTRON® T881 SPECIFICATIONS	---	28
1 YEAR LIMITED HARDWARE WARRANTY	---	29

I - GENERAL INFORMATION

This user manual will guide you through the functions and usage of your SWAGTRON® T881. Before operating this device, read all the instructions for safe assembly, charging, and usage.

Upon unpacking, please inspect the SWAGTRON® T881 for any signs of physical damage or defects.

Ensure that the SWAGTRON® T881 is fully charged before using.

If you have questions, contact SWAGTRON® before you attempt to use or return your hoverboard.

1.1 ABOUT THE SWAGTRON® T881

The SWAGTRON® T881 is a self-balancing, personal transporter that uses gyroscopic technology to revolutionize the way you travel. Steering and stopping are controlled by dynamic equilibrium all based on the shifting of your body weight.

It's environmentally-friendly and uses only the highest quality components and industry-leading safety features.

1.2 WHAT'S IN THE BOX?

- + SWAGTRON® T881 Hoverboard
- + Charging Unit / Adapter
- + User manual

1.3 SAFETY NOTICE

The SWAGTRON® T881 has been designed with the utmost safety in mind for its riders. Extra precautions have been taken to protect the user from product hardware malfunctions through our meticulous design and engineering. However, like any riding product, the SWAGTRON® has inherent hazards associated with its use (for example: losing control, falling off or riding it into a hazardous situation). Therefore it is important to read and follow all instructions and warnings in the User Manual and use good judgment in order to ride safely.

By riding the SWAGTRON® T881, the user acknowledges and accepts personal responsibility of all risks associated with the use of the SWAGTRON® T881 Hoverboard, which may include, but are not limited to, muscle injuries, broken bones, lacerations, or other serious injuries that may be sustained while using the T881.



IF YOU ARE EVER IN AN ACCIDENT, PLEASE CONTACT EMS / DIAL 911 IMMEDIATELY.

Maximum Weight	250 lbs / 113.4 kg
Minimum Weight	44 lbs / 20 kg
Maximum Speed	7 MPH / 11 km/h
Max Incline	30°

Please see SECTION IV for safe riding techniques and additional safety information.

1.4 IMPORTANT INFORMATION



TO PREVENT ELECTRIC SHOCK, MATCH THE WIDER PRONG OF PLUG TO WIDE SLOT IN OUTLET. FULLY INSERT.

WARNING– RISK OF FIRE – No user serviceable parts



AVERTISSEMENT – Risque d'incendie – Aucune des pièces ne peut être réparée par l'utilisateur

equipment
operate this



FCC Regulations state that any unauthorized changes or modifications to this not expressly approved by the manufacturer could void the user's authority to equipment.



This product satisfies FCC Regulations when shielded cables and connectors are used to connect the unit to other equipment. To prevent electromagnetic interference with electric appliances such as radios and televisions, use shielded cables and connectors for connections.

DECLARATION OF CONFORMITY:

This device complies with Part 15 of the FCC Rules.

Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC RELATED INFORMATION:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- + Reorient or relocate the receiving antenna.
- + Increase the separation between the equipment and receiver.
- + Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- + Consult the dealer or an experienced radio/TV technician for help.

The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate the equipment.



This device complies with Industry Canada's licence-exempt RSSs. Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes : (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible

d'en compromettre le fonctionnement.


1.5 DISPOSAL AT END-OF-LIFE

This product must not be disposed of by incineration, landfilling, or mixing with household trash. Improper disposal of the battery contained within this product may result in the battery heating up, rupturing, or igniting which may cause serious injury. The substances contained inside the battery present chemical risks to the environment. The recommended disposal for any SWAGTRON® T881 at its end-of-life is to dispose of the entire unit at or through an e-waste recycling center, program, or facility. Local regulations and laws pertaining to the recycling and disposal of lead-acid batteries and/or products containing them will vary according to country, state, and local governments. You must check laws and regulations corresponding to where you live in order to properly dispose of the battery and/or unit. It is the user's responsibility to dispose of their waste equipment properly in accordance with local regulations and laws.

For additional information about where you should drop off your batteries and electrical or electronic waste, please contact your local or regional waste-management office, your household waste disposal service, or your point-of sale.

II - PRODUCT FEATURES

2.1 SWAGTRON® T881 DIAGRAM



2.2 SWAGTRON® SENTRYSHIELD® – PATENTED MULTILAYERED PROTECTION

Your safety is our top priority. That's why the T881 utilizes a premium quality lead-acid battery pack that is specifically designed for your Hoverboard.

A Smart Battery Management System (BMS) that constantly monitors the following areas for your utmost safety:

- + Overvoltage
- + Temperature increases
- + Overcharging of the battery
- + Overcurrent and short-circuiting

For more information on the battery specifications, see SECTION V.

2.3 BUILT-IN STARTUP BALANCING

The T881 has a built-in Startup Balancing feature which may be turned on or off via the T881 itself. This feature enhances the unit's self-balancing feature by further stabilizing the board and ensuring that the pedals always face up. By default, this feature is turned on. With this feature on, if the rider falls or otherwise dismounts the unit while moving over an incline, the unit may continue to move on its own as it attempts to balance resulting in damage to others, surrounding obstacles, and/or the unit itself.

To turn the feature off, use the power button. While the unit is powering on, quickly press and release the power button a second time. A confirmation beep will issue. Follow the same steps to turn the feature off/on again.



If you decide to use this feature, it is recommended to ride only on surfaces which are completely flat with stable terrain. When the unit is on and this feature is on, do not place your hands on or attempt to grasp the unit anywhere near the wheels or fenders as doing so may cause the wheels to spin on their own for a brief moment. If lifting the unit, turn it off before lifting. Do not lift or carry the unit when this feature is on and the board is powered on.

Failure to adhere to these warnings and/or instructions will result in injuries including but not limited to: abrasions, lacerations, smashed fingers and/or amputation of fingers, injury of others, and damage to surrounding objects.

III – HOW TO RIDE

Get ready to ride with swag! The instructions below will ensure that you have a comfortable and safe riding experience with your T881. Please read carefully.

3.1 OPERATING STEPS

Before attempting to ride, charge your T881 with the included charging adapter. Charge time can take up to 5.5 hours. For detailed information on how to charge see Section 5.1.


1. Press the power button to turn the T881 on.
2. Step on one pedal to trigger the sensor. The system will enter self-balancing mode. Then, step on the second pedal with your other foot quickly.
3. Stand upright but relaxed. Do not make any sudden or jerking movements.

The T881 has 4 sensors below the pedals. When the rider steps on a pedal, the T881 will adjust itself to balance automatically.



Step 1

Press the power button to turn on your Swagtron.



Step 2

Step on one pedal to trigger the foot-switch. The system will enter self-balancing mode with system indicator light flashing.




NOTE:

When riding the T881, you must make sure both feet are touching the pedals for proper detection. Do not put other objects on the pedals as this could cause T881 to lock or move on its own..



NOTE:

- + Do not tilt forward or backwards beyond 10 degrees, as the T881 may malfunction.
- + The T881 will not function if it flips upside down.
- + Avoid uneven or rocky surfaces as the T881 may not function properly.
- + Avoid hills or slopes with inclines over 30 degrees.
- + When the rider exceeds the maximum speed, the T881 may sound a warning alarm.



3.2 DIAGRAM OF OPERATION

The SWAGTRON® Hoverboard self-balances and moves because of Dynamic Equilibrium. This is generated by the shifting of your body weight. The T881 uses an internal gyroscope with acceleration sensors to move based on your center of gravity. When you lean forward, it will sense your actions and accelerate. When you need to turn, slow down and gently shift the weight on your left or right foot to turn towards the opposite direction.

MOVE FORWARD

Shift your weight forward to move directly ahead.

STOP

Align your body to an upright, straight position.

TURNING LEFT

Shift your weight slightly on the left pedal to turn left.

TURNING RIGHT

Shift your weight slightly on the right pedal to turn right.

STEPPING OFF THE SWAGTRON®

Make sure the SWAGTRON® is completely stopped, then step back with your dominant foot first then quickly step off with the other foot. Please be careful!

CAUTION


The SWAGTRON® has a dynamic stabilization system that keeps you upright. However, it will stop

detecting you if you lean too far left or right or if you take a foot off of the hoverboard. Slow down before turning or you may fall off.



NOTE:

+ When riding at higher speeds, avoid turning too fast as this may result in accidents.



- + Avoid riding sideways or turning on slopes. The self-balancing sensors may malfunction and may require recalibration.
- + Do not step on the center pivot point of the T881.
- + If the T881 flips over or rotates more than 180 degrees, motor and riding capability will be disabled. To restore normal functions, power off the unit then and power the unit back on. After this, continue to ride as normal.

3.3 CALIBRATION

If your SWAGTRON® T881 seems to pull to the left or right during your ride, you may need to recalibrate its sensors. The process requires a flat stable surface and a level. Levels may be purchased separately at most hardware stores or level apps may be downloaded with most smartphones. To calibrate your unit, follow the instructions below.

1. Power your T881 off.
2. Rotate the T881 until both pedals are level over the ground. For best results, use a level.
3. While the T881 remains level, hold the power button down to turn on the unit and keep holding the button down.
4. Wait an additional 3 seconds and you will hear a single beep. Release the power button.



5. Press the power button again to turn the T881 off.
6. Once again, press the power button to turn on your newly calibrated T881.

If the T881 is still not calibrated correctly, repeat step 1 to 6 or contact customer support for additional assistance.

IV – SAFE RIDING TECHNIQUES

Although the SWAGTRON® T881 is designed with gyroscopic balancing technology in order to maintain maximum stability, it is still possible to “override” the SWAGTRON® and tip over when riding too fast. Practicing these techniques can help ensure that you have a safe, fun riding experience.

CAUTION

- + All riders of all ages must wear appropriate clothing and safety gear including knee pads, elbow pads, and an ASTM F1492 approved helmet.
- + When going through entryways, remember you are taller.
- + Avoid wearing anything that can drape over or get caught into/under the wheels.
- + Wear flat, close-toed shoes to maintain flexibility and stability.
- + Keep your feet on the pedals. Taking your feet off the SWAGTRON® while riding is incredibly dangerous.
- + Ride on even pavement or smooth roads. Relax your legs while riding and keep your knees slightly bent. This helps maintain balance when you encounter uneven ground.
- + Ensure your speed is safe to yourself and others, and be ready to stop at any time.
- + When riding near others, keep a safe distance to avoid collisions.
- + Be aware of your surroundings at all times. Your eyes are your best tool to safely avoid obstacles and unsafe surfaces.
- + Stay in open spaces and flat areas. Avoid steep slopes or areas with traffic areas until you’re familiar with riding.

- + The SWAGTRON® can only support the weight of one person at a time.
- + Remember, only ride the SWAGTRON® where it is permitted. You MUST comply with local laws and give way to pedestrians.



WARNING:

- Never ride at high speeds on uneven terrain or slopes.*
- Never perform stunts or turn abruptly without checking your surroundings.*
- Never carry one or more passengers on the SWAGTRON® with you.*
- Never carry heavy items while riding.*
- Never ride in the rain, dark, or dimly lit areas.*
- Never use the T881 to do anything that may cause personal injury or property damage.*
- Never ride backwards for long distances or at high speeds.*
- Never step off the T881 when it is in motion.*
- Never place anything on the rider detection pads except your feet. Doing so could interfere with the Rider Detection system and may allow the T881 to travel on its own, risking collision with a person or property and causing injury or damage.*
- Never operate your T881 near flammable vapor, liquids, dust, or other fire hazards.*
- Never ride your T881 after consumption of alcohol, drugs, or while intoxicated. You can be arrested for drunk driving.*

FAILURE TO USE COMMON SENSE AND HEED THE ABOVE WARNINGS INCREASES THE RISK OF SERIOUS INJURY, OR IN VERY RARE CASES, DEATH. USE WITH APPROPRIATE CAUTION AND SERIOUS ATTENTION TO SAFE OPERATION.

V – BATTERY INFORMATION

Item	Parameters
Battery Type	Lead-Acid Battery Pack
Charging Time	5.5 Hours
Battery Voltage	24V
Working Temperature	32°F ~ 104°F
Charging Temperature	32°F ~ 104°F
Storage Temperature	14°F ~ 122°F
Storage Humidity	65±20%RH



For best results, charge between 50°F ~ 86°F (10°C ~ 30°C).

5.1 CHARGING THE T881

For the safety of yourself and others and to extend the battery's life, please be sure to observe the following instructions.

1. Plug the charger into a grounded wall outlet (100–240V; 50–60Hz).
2. Verify that the green light is on, then plug the other end of the charging unit into the T881.
3. When the indicator light changes from red to green, the battery is fully charged.
4. Total charging time is approximately up to 5.5 hours.

Use only the charging adapter provided with your T881. If you have lost or misplaced your charger, contact customer support to obtain a replacement.

 NOTE:

- + When the battery is fully charged, please stop charging and unplug the unit.
- + Please keep your charging environment clean and dry.
- + If the charging port is damp or has any liquid on it, do not charge your hoverboard.
- + In order for the battery to operate at maximum efficiency, avoid charging your T881 in extremely hot or extremely cold environments.

DO NOT charge the battery in the following cases:

- + There is excessive odor or heat.
- + Leakage or physical damage.

Disassembly and battery maintenance should only be performed by an authorized professional. DO NOT touch or consume any substances leaking out of the battery. DO NOT allow children and animals to touch or consume the battery.

5.2 BATTERY INDICATOR

When the battery indicator is at the lowest level or starts flashing, you MUST cease operation of your T881 immediately.



NOTE:

- + Indicators cannot be turned off.
- + Immediately stop riding the T881 if the warning light is flashing. The unit may be unable to properly self-balance.
- + If the battery is overloaded, its temperature has become too hot. A short buzzer will sound and the System Indicator will begin to flash. Gradually slow down, get off, and power down the unit to allow it to cool down. Once the battery and unit have had time to cool down, the unit will power up as normal. If the problem persists, do not ride the unit and contact customer support immediately.

5.3 RANGE PER CHARGE

The maximum distance for which you can ride a fully charged T881 is 4.8 miles. However, many factors need to be considered when determining the actual range per charge.

Factor	Comment
Speed and Riding Style	Keep a moderate, consistent speed. Frequent start, stops, acceleration, and deceleration will reduce riding range.
Topography	Rough terrain or slopes can decrease your range due to motor use. Ride on smooth or even roads for maximum performance.
Weight	The weight of the rider can influence your distance.

Factor	Comment
Temperature	Avoid too hot or too cold environments, as the motor will decrease power to protect itself.



NOTE:

Max speed and duration were obtained through continuous lab tests under ideal conditions. Actual performance may be reduced based on a variety of factors. In order to provide full knowledge to our customers, we have provided maximum performance information.

5.4 SAFETY WARNINGS

When Using the Battery



(1) Misusing the battery may cause the battery to get hot, rupture, or ignite and cause serious injury. Be sure to follow the safety rules listed below:

+ Do not place the battery in fire or direct contact with heat.

+ Do not pierce the battery with sharp objects, strike the battery with a hammer, step on the battery, or otherwise subject it to strong impacts or shocks.

+ Do not expose the battery to water or any liquids, or allow the battery to get wet.

(2) Do not disassemble or modify the battery. The battery contains safety and protection devices which, if damaged, may cause the battery to generate heat, rupture or ignite.

(3) Do not place the battery on or near fires, stoves, or other high-temperature locations. Do not place the battery in direct sunlight, or use or store the battery inside cars in hot weather. Doing

so may cause the battery to generate heat, rupture or ignite. Using the battery in this manner may also result in a loss of performance and a shortened life expectancy.



(1) If the device is to be used by children, the caregiver should explain the contents of the user manual to the children. The caregiver should provide adequate supervision to ensure that the device is being used as explained in the user manual.

(2) Immediately discontinue use of the battery if, while using, charging, or storing the battery, the battery emits an unusual smell, feels hot, changes color, changes shape, or appears abnormal in any other way.

(3) Do not place the batteries in microwave ovens, high-pressure containers, or on induction cookware.

(4) In the event that the battery leaks and the fluid gets into one's eye, do not rub the eye. Rinse well with water and immediately seek medical care. If left untreated, the battery fluid could cause damage to the eye.

While Charging



(1) Be sure to follow the rules listed below while charging the battery. Failure to do so may cause the battery to become hot, rupture or ignite and cause serious injury.

When charging the battery, use a specified battery charger provided in the package.

Do not place the battery in or near fire, or under direct sunlight.

(2) Do not continue charging the battery if it does not recharge within the specified charging time. Doing so may cause the battery to become hot, rupture or ignite.

The temperature range within which the battery can be charged is 32°F ~ 104°F. Charging the battery at temperatures outside of this range may cause the battery to become hot or to break. Charging the battery outside of this temperature range may also harm the performance of the battery or reduce the battery's life expectancy.

When Discharging the Battery

Do not discharge the battery using any device except for the specified device. When the battery is used in devices aside from the specified device it may damage the performance of the battery or reduce its life expectancy, and if the device causes an abnormal current to flow, it may cause the battery to become hot, rupture or ignite and cause serious injury.



The temperature range within which the battery can be discharged is 32°F ~ 104°F. Use of the battery outside of this temperature range may damage the performance of the battery or reduce its life expectancy.

VI – MAINTENANCE

Your SWAGTRON® T881 needs to be maintained in order to always have the best riding experience.



NOTE:

- + Always ensure the power is off and the unit is not being charged during maintenance.
- + Attempting to repair or modify your T881 can void all warranties. Only authorized repair centers may open and service the T881.

If you need assistance with your T881, please contact SWAGTRON® support at 1-(844)-299-0625.

6.1 CLEANING

Proper cleaning of your SWAGTRON® T881 can promote a longer lifespan and a smooth riding experience.

- + Wipe the outer body / shell of your T881 with a soft, dry microfiber cloth.
- + Check around the wheels and ensure that there is no blockage.
- + The T881 meets IPX4 water-resistance, meaning it can withstand splashes. However, do not submerge the T881 in water.
- + Do not let water and liquids get into the T881's electric parts or battery.

6.2 STORAGE

Below are some tips to consider when storing your SWAGTRON® T881.

- + Before storing your T881, fully charge the battery to avoid over discharging due to non-use.
- + Discharge and recharge the battery every three months.
- + Store your T881 indoors at a dry and suitable temperature. DO NOT store it in an unheated garage or shed.

6.3 TRANSPORTATION



Department of Transportation (DOT) requirements affecting the packaging and transportation of all batteries containing acid or alkali are contained in the Code of Federal Regulations – 49 CFR Section 173.159.

SWAGTRON® T881 batteries are: UN2800, Batteries, Wet, Non-spillable. The batteries have been tested and

meet the non-spillable criteria listed in 49CFR§173.159. Non-spillable batteries are accepted in CFR 49, Subchapter C requirements under the following conditions:

1. The batteries must be protected against short circuits and securely packaged.
2. The batteries and their outer packaging must be plainly and durably marked “NON-SPILLABLE” or “NONSPILLABLE BATTERY.”

VII – SWAGTRON® T881 SPECIFICATIONS

Item	Parameters
Net Weight	23 lbs
Dimensions	24 x 4 x 7 in
Chassis Height	1.77 in
Pedal Height	4.52 in
Chassis Material	ABS Hard Casing
Tire Material	Hard Rubber Tire / Aluminum Rimmed Wheels
Maximum Speed	7 MPH / 11 km/h
Turning Radius	0°
Climbing Capacity	30°
Maximum Load	250 lbs / 113.4 kg
Minimum Load	44 lbs / 20 kg
Power	110V – 240V
Battery Type	Rechargeable Lead Acid Battery
Battery Shielding	Fire-Retardant Plastic Casing
Charger Voltage	30.2Vdc, 0.5A
	Model PS20D302K0500UD manufactured by SHENZHEN FLYPOWER TECHNOLOGY CO LTD Input:100–240Vac,50/60Hz, Output:30.2Vdc,500mA

1 YEAR LIMITED HARDWARE WARRANTY

Your SWAGTRON® T881 Hoverboard (“Product”) includes a One Year Limited Hardware Warranty (“Warranty”). The Warranty covers product defects in materials and workmanship under normal use. This Warranty is limited to residents of the United States and Canada only and is available only to original purchasers. This Warranty gives you specific legal rights and you may also have other rights which vary from state to state.

This Warranty starts on the date of your purchase and lasts for one year (the “Warranty Period”). The Warranty Period is not extended if the Product is repaired or replaced. We may change the availability of this limited warranty at our discretion, but any changes will not be retroactive.

Warranty services are provided by SWAGTRON®. If a hardware defect arises and a valid claim is received within the Warranty Period, at its option and to the extent permitted by law, SWAGTRON® will: (1) repair the hardware defect by using new or refurbished parts that are equivalent to new in performance and reliability; or (2) exchange the Product with a product that is new or refurbished which is substantially equivalent to the original product. This Warranty is for one replacement only of like-items and does not cover items out of production if the product is no longer made or stocked. This Warranty is not assignable or transferable. The original purchaser may call SWAGTRON’s toll-free number at 1-844-299-0625 for service request.

When a product or part is exchanged, any replacement item becomes your property and the replaced item becomes SWAGTRON’s property. This warranty only covers technical hardware defectiveness during the warranty period and under normal use conditions. SWAGTRON® does not warrant uninterrupted or error-free operation of this Product.

This Warranty does not cover any damage due to: (a) transportation; (b) storage; (c) improper use; (d) failure to follow the product instructions or to perform any preventive maintenance; (e) modifications; (f) unauthorized repair; (g) normal wear and tear; or (h) external causes such as accidents, abuse, or other actions or events beyond our reasonable control.

Important: Do not disassemble the Product. Disassembling the Product will void this Warranty. Only SWAGTRON® or a party expressly authorized by SWAGTRON® should perform service on this Product.

DISCLAIMER OF WARRANTY: THE REMEDIES DESCRIBED ABOVE ARE YOUR SOLE AND EXCLUSIVE REMEDIES AND OUR ENTIRE LIABILITY FOR ANY BREACH OF THIS LIMITED WARRANTY. OUR LIABILITY SHALL UNDER NO CIRCUMSTANCES EXCEED THE ACTUAL AMOUNT PAID BY YOU FOR THE DEFECTIVE PRODUCT, NOR SHALL WE UNDER ANY CIRCUMSTANCES BE LIABLE FOR ANY CONSEQUENTIAL, INCIDENTAL, SPECIAL OR PUNITIVE DAMAGES OR LOSSES, WHETHER DIRECT OR INDIRECT.

SOME STATES DO NOT ALLOW THE EXCLUSION OR LIMITATION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES, SO THE ABOVE LIMITATION OR EXCLUSION MAY NOT APPLY TO YOU.

THE DURATION AND REMEDIES OF ALL IMPLIED WARRANTIES, INCLUDING WITHOUT LIMITATION THE WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE LIMITED TO THE DURATION OF THIS EXPRESS LIMITED WARRANTY.

SWAGTRON®

COPYRIGHT © 2018 SWAGTRON. ALL RIGHTS RESERVED.